



#### TERMS AND CONDITIONS FOR ULTRATECH CORROPROTECT

- Proper shuttering / formwork to sustain the concrete pressure.
- Compaction of concrete using suitable vibrators.
- Timely curing and protection of concrete.