



#### TERMS AND CONDITIONS FOR ULTRATECH PERVIOUS

- Prepare properly compacted subgrade.
- Place 8"-24" open graded stone (this prevents saturation of pervious concrete).
- Place pervious concrete of 150mm thickness over the base course.
- Curing to be started within 24 hours and should be continued for at least 7 days.